Full Maintenance Schedule

EVERY 3000 MILES



- Perform multi-point inspection
- Change engine oil and replace oil filter (Up to 5 quarts of oil. Perform at specified mileage interval or every 6 months, whichever occurs first)
- Rotate and inspect tires; check wheel end play and turning noise

Mileage	15k	30k	45k	48k	60k	75k	90k	99k	105k	120k	135k	150k
Change engine oil and replace oil filter (Up to 5 quarts of oil. Perform at specified mileage interval or every 6 months, whichever occurs first)	x	x	x	x	x	x	x	x	x	x	x	x
Perform multi-point inspection	x	x	x	x	x	x	x	x	x	x	x	x
Rotate and inspect tires; check wheel end play and turning noise	x	x	x	x	x	x	x	x	x	x	x	x
Inspect automatic transmission fluid level (if equipped with underhood dipstick)	x	x	x		x	x	x		x	x	x	x
Inspect brake pads/shoes/rotors/drums, brake lines and hoses, and parking brake system	x	x	x		x	x	x		x	x	x	x
Inspect engine cooling system and hoses	x	x	x		x	x	x		x	x	x	x
Replace engine air filter	x	x	x		x	x	x		x	x	x	x
Replace fuel filter	x	x	x		x	x	x		x	x	x	x
Inspect and lubricate all non-sealed steering linkage,ball joints,suspension joints,half and drive-shafts and u-joints	x	x	x		x	x	x		x	x	x	x
Inspect complete exhaust system and heat shields		x			x		x			x		x
Inspect 4x2 front wheel bearings; replace grease and grease seals, and adjust bearings		x			x		x			x		x
Change automatic transmission fluid and filter		x			x		x			x		x
Change rear axle lubricant				x				x				x
Change Premium Gold engine coolant								x				x
Inspect accessory drive belt(s)								x				
Replace platinum spark plugs								x				
Replace PCV valve										x		
Replace accessory drive belts (if not replaced within last 100,000 miles)												x